






Instructions for use





Floors

6mm should be used over existing timber floors and should be screwed at 250mm centres (more if there is movement in the substrate).

Tile backer should be fixed with the rough face upwards. It does not require primer a good quality tile adhesive should be applied by notched trowel the thicker the tile the deeper the notch is required.

Tiles should be placed whist the adhesive is still wet so don't overspread as placing tiles late can cause failures.

Where there is no timber floor and you are planning to fix tile backer to the joists are at 400mm centres 12mm can be screwed directly, ensure that board joints are supported by the joist as you cannot join in mid air between joists. Screws should be 45mm minimum length at 150 mm centres and tile backer place with the rough side towards you.

Walls

Wall tiling should always be carried out on 12mm on wall situations as often there is considerable weight to be considered.

The 12mm tile backer should be fitted rough side toward you and does not require a primer.

The board should be fixed directly to the studs @400mm centres with minimum 45mm screws at 150mm centres.

Tile backer handling

Tile backer is easy to work with and can be scored and snapped for ease of use. Tile backer can also be cut by saw and normal dust mask precautions should be taken.




Frequently asked questions

Can I fix through
Coolag tile backer?
Yes, all fixings should be made directly into studs or noggins fixed firmly between the studs.

Which side should Coolag tile backer should be fixed with the rough side be tiled on? facing the inside of the room.

Can I use Coolag tile backer Yes, it is suitable for under floor heating. Boards should always be placed below the heating element. heating?

Can I fix through
Use galvanised, self drilling, self counter-sinking screws.
For 6mm use 25mm screws, and 38mm screws on 12mm
Coolag tile backer.







TILE BACKER CEMENT BOARD

Product Info

Thickness	Size (mm)	Pallet sizes	Weight (kg)
6mm	1200 x 800	100	4
12mm	1200 x 800	100	8

IPP Ltd. Bradwell Hall, Bradwell on Sea, Essex CMO 7HX Telephone 01621 776252 Email sales@intpetro.com

If you have any technical difficulties, please give us a call on 01621 776252. We would be happy to help you out!

