



LX-360

Deep fill, fibre reinforced levelling from

3-60mm

DUNLOP LX-360 FIBRE LEVELLER

The versatile, deep fill and fast setting leveller. LX-360 can tackle a wide range of substrates, and sets in as little as 3 hours – regardless of depth.



FEATURES:



Fibre reinforced



3-60mm depth



Walkable in just 3 hours



30 minute pot life




A 20kg bag covers 4m² at 3mm deep



HOW TO:


Apply LX-360 over plywood or tongue and groove floorboards.

1. Prepare



Ensure boards are rigid, clean, dry, free of any contaminants incompatible with adhesion, and securely fixed (screwed to joists at 300mm centres).

2. Prime



Prime with 2 coats of DUNLOP SBR diluted at 1:2 (primer:water). Apply the second coat at 90° to the first, allowing to dry between coats.

3. Mix




Add one 20kg bag to 4.2 litres of clean water and mix to a smooth mortar with an electric drill mixer. Allow to stand for 2 minutes, re-mix for 30 seconds then apply.

4. Apply



Pour, spread and smooth using a steel trowel to the required depth, evening out any low points in the subfloor.

5. Finish



Walkable from 3 hours, tile after only 4 hours, and install LVT, sheet vinyl, carpet etc. after 24 hours.

SUITABLE FOR:

- Plywood/tongue & groove floorboard
- Concrete
- Cement and Sand Screeds
- Terrazzo
- Internal flooring grade asphalt
- Quarry tiles
- Sound tile adhesive residues
- Electric UFH
- Heated screeds

Note: Please refer to datasheet for full details of application.

Dunlop Sales: 01782 591160

Dunlop Technical: 01782 591120

info@dunloptrade.com
www.dunloptrade.com



Scan for more product information, datasheets, and videos.

Dunlop and the Flying D device are trademarks of Sumitomo Rubber Group and are used under license by Building Adhesives Ltd.

Dunlop LX-360 bag requirement guide



	Depth (mm)																		
	3	4	5	6	7	8	9	10	11	12	13	14	15	20	25	30	40	50	60
Area (m ²)	1	1	1	1	1	1	1	1	1	2	2	2	2	2	3	3	4	5	6
	2	1	1	1	2	2	2	2	2	3	3	3	3	4	5	6	7	9	11
	3	1	2	2	2	2	3	3	3	4	4	4	4	6	7	8	11	13	16
	4	2	2	2	3	3	3	4	4	4	5	5	5	6	7	9	11	14	17
	5	2	2	3	3	3	4	4	5	5	6	6	6	7	9	11	13	17	22
	6	2	3	3	4	4	5	5	6	6	7	7	8	8	11	13	16	21	26
	7	2	3	3	4	5	5	6	6	7	8	8	9	9	12	15	18	24	30
	8	3	3	4	5	5	6	7	7	8	9	9	10	11	14	17	21	28	34
	9	3	4	4	5	6	7	7	8	9	10	10	11	12	16	20	23	31	39
	10	3	4	5	6	6	7	8	9	10	11	12	12	13	17	22	26	34	43
	11	3	4	5	6	7	8	9	10	11	12	13	14	15	19	24	29	38	47
	12	4	5	6	7	8	9	10	11	12	13	14	15	16	21	26	31	41	51
	13	4	5	6	7	8	9	10	12	13	14	15	16	17	23	28	34	45	56
	14	4	5	6	8	9	10	11	12	14	15	16	17	18	24	30	36	48	60
	15	4	6	7	8	9	11	12	13	15	16	17	18	20	26	32	39	51	64
	16	5	6	7	9	10	11	13	14	15	17	18	20	21	28	34	41	55	68
	17	5	6	8	9	11	12	14	15	16	18	19	21	22	29	37	44	58	73
	18	5	7	8	10	11	13	14	16	17	19	20	22	23	31	39	46	62	77
	19	5	7	9	10	12	13	15	17	18	20	21	23	25	33	41	49	65	81
	20	6	7	9	11	12	14	16	17	19	21	23	24	26	34	43	51	68	85
	30	8	11	13	16	18	21	23	26	29	31	34	36	39	51	64	77	102	128
	50	13	17	22	26	30	34	39	43	47	51	56	60	64	85	107	128	170	213
	100	26	34	43	51	60	68	77	85	94	102	111	119	128	170	213	255	340	425

Calculation example:
13.44m² kitchen to be covered at 5mm depth.

$$\text{Bags needed} = \frac{\text{Consumption} \times \text{Depth} \times \text{Area}}{20} = \frac{1.7 \times 5 \times 13.44}{20} = 5.7 \text{ (rounded up to 6 bags)}$$